




Alpha Elite *Quick Start Guide*

TURNING YOUR PAGER ON

Press .

TURNING YOUR PAGER OFF



1. From the Function menu, press  to move the cursor to .
2. Press  twice.

FUNCTION MENU








Provides access to the features described in this quick reference card and in your user's guide.

1. Press .
2. Press  or  to move within the Function menu.



RECEIVING/READING MESSAGES


1. Press any button to stop the alert.
2. Press  to display your message.
3. Press  to view the next screen.

LOCKING AND UNLOCKING MESSAGES


1. From the Message-status screen, press  or  to select the message you want to unlock/lock.
2. Press .
3. Press  to move the cursor to  or .
4. Press .

DELETING MESSAGES



1. From the Message-status screen, press  or  to select the message you want to delete.

2. Press ●.
3. Press ► to move the cursor to .
4. Press ● twice.



SETTING THE TIME AND DATE

1. From the Function menu, press ◀ to move the cursor to .
2. Press ●.
3. Press ► to move the cursor to the hour digit.
4. Press ▲ or ▼ to adjust the hour.
5. Repeat steps 3 and 4 to adjust the minutes, AM/PM/24 hr., month, day, and year.
7. Press ● to activate the setting.

SETTING ALARMS









1. From the Function menu, press ◀ to move the cursor to .
2. Press ●.
3. Press ▼.
4. Press ► to move the cursor to the alarm symbol.
5. Press ▲ or ▼ until <  > is displayed.
6. Follow steps 3–6 in *Setting the Time and Date* to set the alarm time.

To set a message alarm:







1. With the message displayed, press ●.
2. Press ► to move the cursor to .
3. Press ▲ or ▼ until <  > is displayed.
4. Follow steps 3–6 in *Setting the Time and Date*.

Note: To set a daily pager or message alarm, press ▼ until double dashes are displayed for the month, day and year (--/--/--).

STORING MESSAGES IN YOUR NOTEBOOKS





1. From the Message-status screen, press , , , or  to move the cursor to the message you want to move into the notebook.
2. Press .
3. Press  to move the cursor to .
4. Press  to store the message.

PRIVATE TIME ON





1. From the Function menu, press  to move the cursor to .
2. Press .
3. Press and release  until  is displayed.
4. Follow steps 3–4 in *Setting the Time and Date* to set the on and off times.
5. Press  to activate your selection.

To turn private time off, in step 4 above, press and release  until  is displayed.








TO ENABLE/DISABLE DISPLAY ZOOM

1. From the Function menu, press  to move the cursor to  enable or  to disable.
2. Press .


















PAGER SYMBOLS

-  Power On
-  Audible Alert Mode on
-  Private Time enabled
-  Alarm enabled



















Message Status Symbols

-  Locked Message
-  Maildrop Alert Enabled
-  Maildrop Alert Disabled
-  Personal Message
-  Memory Full
-  Alarmed Message
-  Notebook

Function Menu Symbols

-  Choose Alert
-  Set Time and Alarm
-  Set Private Time
-  Display Zoom On
-  Display Zoom Off
-  Set Silent Alert
-  Set Audible Alert
-  Turn Pager Off
-  Escape (to Message-status screen)
-  Delete Message
-  Delete All Messages
-  Lock Message
-  Unlock Message
-  Turn Maildrop Alert On
-  Turn Maildrop Alert Off
-  Set Message Alarm
-  Add to Notebook

Other Symbols

-  Message Continuation
-  24 Hour Time
-  AM Time
-  PM Time
-  Enable Alarm
-  Disable Alarm
-  Private Time Enabled
-  Private Time Disabled
-  Low Battery Indicator
-  1/4 Battery Indicator
-  1/2 Battery Indicator
-  3/4 Battery Indicator
-  Full Battery Indicator
-  Out of Range
-  Truncated Message
-  Errored Data Indicator
-  Alphanumeric Missing Fragment Indicator
-  Long Numeric Missing Fragment Indicator