













ICON SYMBOLS

-  – Reception Area
-  – Beep Alert On
-  – Melody Alert On
-  – Vibe Alert On
-  – Alarm On
-  – **Automatic On/Off**
-  – Message Lock
-  – Duplicate Message
- new** – New Unread Message
-  – Low Battery
-  – Message Continuation

Sun Telecomm
AN1000

Quick Start Guide

READ AND FUNCTION BUTTONS



-  READ BUTTON
 - Read messages.
 - Select setting and features in Function mode.
 - Turn pager on
-  FUNCTION BUTTON
 - Enter Function mode.
 - Turn the light on or off.

Press  and  together to move to the Main screen.

TURNING PAGER ON

Press and hold  for 2 seconds.

TURNING PAGER OFF

1. Press  to enter the Function mode.
2. Press  2 times until "POWER OFF?" is displayed.

RECEIVING/READING MESSAGES



1. Press  to stop the Alert and read messages.

The following information will be displayed:

Message number, time stamp, message.

Messages are displayed from newest to oldest.





DELETING A MESSAGE

1. After reading message, press  two times until "DELETE?" is displayed.
2. Press  to confirm your decision and the next message is displayed.




DELETING ALL MESSAGES

1. Press  2 times until "DELETE ALL?" is displayed.
2. Press  to delete all messages.





LOCKING AND UNLOCKING MESSAGES

1. Press  while the message is displayed.
2. When "LOCK?" appears, press  to lock the message. The Lock icon will be displayed.
1. To unlock a message, press  while the lock message is displayed.
2. When "UNLOCK?" appears press  to unlock the message.

SETTING THE TIME & DATE

1. Press  4 times until "DATE-TIME?" is displayed.
2. Press  to change to time or date.
3. Press  to advance to the next field.

SETTING THE ALARM

1. Press  3 times until "SET ALARM?" is displayed.
2. Press  to select an Alarm setting mode.
3. To choose and set desired condition, press  button to toggle
4. To move to each field (hr, min, am/pm) press the  button