





SunTelecom

ST902 Quick Start Guide







TURNING PAGER ON

Open the flip lid and press any key to turn your pager on. The pager will display the Status screen.








TURNING PAGER OFF

- From the Main menu, press  or  to highlight Power Off and press 
- Highlight Yes and press 





READING MESSAGES

- To read a message, (while previewing) press  or  to highlight the desired message and press 
- Press  or  to scroll through the text of a message or press  to page down through the message








COMPOSING AND SENDING A MESSAGE

- From the Main menu, press  or  to highlight Write and press 
- After you finish composing the message, press  and select the Select Address icon
- Select the address to send to
- To send, return to the Write screen, by selecting "Done Selecting", highlight the Send icon (press  or , if needed) and press 








DELETING A MESSAGE

- From the Read menu, press  or  to highlight the inbox containing the message you want to delete and press 
- Select the message to delete and press 







SETTING DATE AND TIME

- From the Main menu, press  or  to highlight Preferences and press 
- Select Setup and press 
- Press  to select Set Time & Date
- Press Nav buttons to move between fields and change the hour, minutes, and date by pressing 
- Press  to save and exit

SETTING THE ALARM

- From the Main menu, press  or  to highlight Set Alarm and press 
- Press  or  to change the “Mode”, “Snooze” and Alarm Tone, press  to set the time and date
- At any time, press  to save the changes and return to the Main menu

PRIVATE TIME

- From the Main menu, press  or  to highlight Preferences and press 
- Press  to highlight Private Time and press 
- Press Nav Buttons to activate Private Time and set the alert at End option. Press  to set the start and stop times.