

# QUICK START GUIDE



## T52 TWO-WAY PAGER

### TURNING PAGER ON

Open the flip lid and press any key to turn your pager on. The pager will display the Status screen.

### TURNING PAGER OFF

- From the Main menu, press or to highlight Power Off and press button.
- Highlight Yes and press button.

### READING MESSAGES

- To read a message, (while previewing) press or to highlight the desired message and press button.
- Press or to scroll through the text of a message or press to page down through the message button.

### COMPOSING AND SENDING A MESSAGE

From the Main menu, press or to highlight Write and press button.

- After you finish composing the message, press button and select the Select Address icon
- Select the address to send to
- To send, return to the Write screen, by selecting "Done Selecting", highlight the Send icon (press or , if needed) and press button.

### PASSCODE SET AND CLEAR

The options available to set and clear the pager passcode depend on the enabled passcode features

- From the Main menu, press or to highlight Preferences and press button.
- Press or to highlight either Set Lock Code or Clear Lock Code as needed and press button.
- Use Set Lock Code to either set or change the passcode. Enter a 4 to 16 character passcode and press button.
- Use Clear Lock Code to remove the passcode. Enter the current passcode and press button.

### DELETING A MESSAGE

- From the Read menu, press or to highlight the inbox containing the message you want to delete and press button.
- Select the message to delete and press button.

### SETTING DATE AND TIME

- From the Main menu, press or to highlight Preferences and press button.
- Select Setup and press button.
- Press to highlight Set Time & Date and press button.
- Press Nav buttons to move between fields and change the hour, minutes, and date by pressing button.
- Press button to save and exit

### SETTING THE ALARM

- From the Main menu, press or to highlight Set Alarm and press button.
- Press or to change the "Mode", "Snooze" and Alarm Tone, press button to set the time and date
- At any time, press button to save the changes and return to the Main menu

### PRIVATE TIME

- From the Main menu, press or to highlight Preferences and press button.
- Press to highlight Private Time and press button.
- Press Nav Buttons to activate Private Time and set the alert at End option. Press button to set the start and stop times.

### BACKLIGHT ON/OFF

- Press and hold button to turn the backlight on
- The backlight will remain illuminated until it times out and returns to the standby screen
- To manually turn the backlight off, close and open the flip lid

### SCREEN LOCKING

- The device screen will lock automatically after 5 min of no activity
- To lock manually, highlight Lock Screen in the Main menu and press button.

### SCREEN UNLOCKING

- From the Status screen, enter the passcode and press button.