

UNIMAX

RING TONE AMPLIFIER



The UniMAX Tone Alert and Ring Tone Amplifier is built to alert you when you have been paged. Place your pager or cellular phone in the UniMAX unit and its high volume audible alert will notify you of an incoming call or page.

The selectable alert tone will increase in volume in 15-second increments for one minute to reach maximum volume or until the reset button is pressed, helping to ensure it will always catch your attention.

The UniMAX device is designed to work with most pagers and cellular phones while on AC or battery power.



WHY UNIMAX PAGERS ARE EFFECTIVE:

- The alert increases in volume until silenced
- Works in loud environments
- Works with most pagers and smartphones
- Works on AC or battery power

KEY FEATURES	BENEFITS
Indicator/Alert	<ul style="list-style-type: none"> • Extra loud alert (>100db) • Status indicator • Low battery indicator • Selectable alert tones (10 tones) • Flexible alert time settings • LED flashing light to indicate a pager or call • Escalating alert
Alerts	<ul style="list-style-type: none"> • Indented volume control knob • Low power consumption • Works with most pagers and cellular phones • Variety of power sources – AC adapter and AA alkaline batteries
Specifications	<ul style="list-style-type: none"> • Battery status indication: <ul style="list-style-type: none"> ○ Battery full LED on (green) ○ Battery low LED flash (red) • Disposable battery life: estimated three weeks • 4.2 ounces • 3.77" W x 3.07" H x 2.00" D
Frequency	<ul style="list-style-type: none"> • Alert tone: Max. >100 db @ 12 in, Min. >70 db @ 12 in
Temperature	<ul style="list-style-type: none"> • Operating temperature: 32°F to 122°F • Storage temperature: 4°F to 140°F
Accessories	<ul style="list-style-type: none"> • AC power adapter • Alpha series insert

